

Assembly and operating instructions Porky's Scrubbing Wall

Dear Customer, please completely read this manual before initial use of your new device and act accordingly. Keep the manual in a safe place for future use and pass it on to any future owner.

1. Use in stables

Porky's Scrubbing Wall is a scrubbing facility for pigs. The device is exclusively intended for this purpose and use for any other purpose is not permitted. Use only accessories and spare parts approved by MEIER-BRAKENBERG.

Porky's Scrubbing Wall is delivered complete with mounting materials, screws and nuts for installation on plastic partition walls and imperial tubes. Wear protective gloves during assembly! The lower opening at the Scrubbing Wall allows water to drain off during cleaning.

2. Installation in stables

Installation on 3 plastic boards and 3 tubes:

Use the delivered U-bolts and washers and one of the upper oblong holes to fasten Porky's Scrubbing Wall on the tubular frame. Mount the lower part of the Scrubbing Wall with 4 machine screws on the partition wall or PVC board. It is possible to install two Scrubbing Walls in adjacent compartments, one on each side of the partition wall - then use machine screws at the top and bottom!

Installation on concrete walls or similar walls:

Should you intend to install the Scrubbing Wall on other types of partition or compartment walls, then use appropriate screws. Such screws are not included in the standard scope of delivery!

We generally recommend double fixation at the 4 corner positions and additionally at a central point in between, if possible.



3. Installation height

Meier-Brakenberg recommends the following installation heights:

- 25 cm for fattening pigs and
- 15 cm for piglets

ATTENTION: In compliance with the Initiative Tierwohl (animal welfare) the installation heights as stated in the list of criteria apply: The installation height is required to suit the body height of individual animals to allow scrubbing!

ATTENTION: It is mandatory to observe the publicly available list of criteria under <http://initiative-tierwohl.de> in order to comply with the directives of the Initiative Tierwohl. This includes the latest specifications, like e.g. the calculation of net compartment spaces which includes allowances for reductions due to permanently installed parts. Each Scrubbing Wall reduces the compartment space by 0.043 sqm!

4. Function

The rough surface structure of the aluminium chequer plate allows the animals to scrub their backs and sides. Depending on the inclination angle the Scrubbing Wall is suitable for animals of any growth period and size.

We are interested in the experience you make. Please send us a picture or e-mail your observations and suggestions to info@meier-brakenberg.de.

- ☞ **Do you have any questions? We would be pleased to help. Please call us!**
Tel.: +49(0) 5262 /99399-0

MEIER-BRAKENBERG GmbH & Co. KG
Brakenberg 29 • 32699 Extertal • Germany
Tel: +49(0)52 62/993 99-0 • Fax: +49(0)52 62/993 993
info@meier-brakenberg.de
www.meier-brakenberg.de

Einweichanlagen • Desinfektion • Tierwaagen • Intensivreinigung • Hochdruckreiniger • Stallkühlung • Tränkeanlagen